How to change the date on your Aspire phone system

From any display phone, with the handset in the cradle:

Press **CALL1**
Dial **#*#***
Dial **12345678**
Dial **HOLD**
Dial **10-01-01**

Following the prompts
Dial Year + **HOLD**
Dial month + **HOLD**
Dial day + **HOLD**
Dial week + **HOLD**
Dial hour +**HOLD**
Dial minute + **HOLD**
Dial second + **HOLD**
Hit the **MSG** key twice
Hit the **Dial** key